

INSTALLATION ON BRICK CROSS SECTION

2X SUPPORT BOARD

DRILL 1/2" HOLE WITH MA-
SONRY BIT

INSERT 5/16" X LONG LEAD
LAG SHIELDS

FASTEN SUPPORT BY SCREW-
ING 5/16" X 3 1/2" HEX HEAD
LAG SCREW

APPLY ADHESIVE TO TOP
OF SUPPORT BOARD

PUSH
SHELF
INTO
POSITION
& SECURE
WITH
FINISH
NAIL

INSTALLATION ON DRYWALL

POSITION MANTEL & PENCIL ALONG OUTSIDE
EDGE

MEASURE BACK FROM LINE THE THICKNESS
OF THE RETURN LEG & SHELF FOR LOCATION
OF 1X SUPPORT BLOCKS

GLUE & NAIL SUPPORT BLOCKS TO STUDS
WHEN POSSIBLE WITH PANEL
ADHESIVE & 10 PENNY COMMON NAILS

NAIL MANTEL ONTO SUPPORT BLOCKS
WITH FINISH NAILS

